

Crocheted Face Covering

Materials:

F hook (or hook needed to obtain gauge)
Worsted weight
Yarn needle
Scissors
Coated paperclip (optional)

Gauge:

Hdc rows worked in BLO:
8 rows and 12 st. = 3 inches

Notes:

All stitches are worked in BLO except the last slst round.

All inc are hdc inc unless otherwise noted.

These masks are intended to have an insert of some kind to make them more effective. You can use a disposable one like a coffee filter or a vacuum cleaner bag cut to size. You can also use a washable fabric or cotton batting liner cut to size and sewn in place. The mask should be washed after each use. If you're using a disposable liner, the liner should be discarded after each use AND the mask should be washed after each use. Please see the CDC recommendations for reusable masks. DO NOT use face masks on children under 2.

Sizes:

Adult (child, small child)

© Copyright Notice

You have permission to sell the finished products from this pattern; I just ask that you please give credit to my website for the pattern and if you sell them online, please provide a link to my website for the pattern. Rewriting, reselling, distributing, or copying the pattern (or its photos) itself is prohibited. Thanks so much for your cooperation. Happy crocheting!

Looking for more patterns?

For more patterns, including various FREE ones: www.AFarmhouseFull.com/crochet



Ch 36 (32, 28)

1.) In second ch from hook slst 3 (2, 2), sc 2, hdc 10 (9, 7), inc, hdc, inc, hdc, inc, hdc 10 (9, 7), Sc 2, slst 3 (2, 2), ch 1 turn, 38(34, 30)

2.) slst 3 (2, 2), Sc 2, hdc 12 (11, 9), inc, hdc 2, inc, hdc 12 (11, 9), Sc 2, slst 3 (2, 2), ch 1 and turn, 40 (36, 32)

3.) slst 3 (2, 2), Sc 2, hdc 30 (28, 24), Sc 2, slst 3, ch 1 and turn, 40 (36, 32)

Adult teen: 4-12.) repeat row 3

Child: 4-10.) repeat row 3

Small child: 4-10.) repeat row 3

NEXT ROW: slst 3 (2, 2), Sc 2, hdc 14 (13, 11), dec, hdc 14 (13, 11), sc 2, slst 3 (2, 2), ch 1 and turn, 39 (35, 31)

NEXT ROW: slst 3 (2, 2), sc 2, hdc 10 (9, 7), hdc hdc2tog, dc 2, 3 dc in next (inc), dc 2, hdc hdc2tog, hdc 10 (9, 7), Sc 2, slst 3 (2, 2), DO NOT CHAIN, DO NOT TURN, 39 (35, 31)

Working in rounds now: ch 18 (16, 14) slst tightly across foundation ch row, ch 18 (16, 14) slst tightly across last row, FO and weave on ends

Optional: weave a paper clip or a small piece of pipe cleaner through the nose area (last row) leaving a small piece out of each end, so you can fold it over to secure. Mold wire to your nose curve.